
View In-Pen Weighing Data Application (View GS Beef Data)

The View In-Pen Weighing Data (GS Beef) application is used to:

- View the performance of an animal or a pen of animals,
- · View specific animal weight and daily gain,
- Identify low performing or light weight animals in a pen,
- Identify heavy animals in a pen and examine their gain to determine which animals may be ready for harvest,
- Select animals to mark (spray).



Number	Description
1	Pen selection
2	Graph displaying distribution in animal
	weights or gains
3	Animals within the weight or gain
	interval selected by the yellow cursor in
	the graph
4	Date selected
5	Choose to display the weight range or
	daily gain range
6	Set the intervals you want weights or
	gains to be organized in
	The average weight and number of
	animals within the interval selected, and
	the total number of animals in the pen
8	The weight range for the interval
	selected
* The same applies when the gain range is selected	
in 5	

View In-Pen Weighing Data Application (View GS Beef Data)

Choose Animals to be Marked (Sprayed)

- · Within the weight or gain interval selected on the graph, click on the animal you want to mark
- To select multiple animals for marking, click on an animal, hold down the *Ctrl* key on your keyboard and click on additional animals you would like to be marked
- Click *Mark* and the Spray Request window will pop up (note: animals will continue to be marked until you have unselected them for marking)

• Make sure the animals listed in the table on the pop-up are animals you want to be marked

• Complete the action by clicking Enter in the pop-up window



Number	Description
1 1	Click on animals within a weight interval to select them to be marked
2	Click the <i>Mark</i> button to set selected animals to be marked
1 2	Animals selected for marking will be shown in the Spray Request pop-up window
4	Click Enter to set selected animals to be marked

